



## End Tower Auto-Reverse

Irrigation Components International offers a universal, easy-to-install automatic stop and reverse package that mounts to any tower and is easy on the budget.

### Product Features

- ◆ Safety and Crash Prevention
- ◆ Allows Machine to Stop from any Tower
- ◆ Unique Four-Piece Control Arm Configuration for Ease of Shipping and Assembly
- ◆ Adjustable, for Broader Base Beams
- ◆ Kit Includes: Arm Assembly, Control Box Mounting Bracket, Control Box, Springs, Turnbuckles, 7 Conductor Cable, Fasteners and Instructions
- ◆ Competitively Priced



For more information, contact your local Irrigation Components branch.

[www.irricomp.com](http://www.irricomp.com)

**Southeast**

(251) 626-5470

[southeast@irricomp.com](mailto:southeast@irricomp.com)

**Southwest**

(806) 318-3854

[southwest@irricomp.com](mailto:southwest@irricomp.com)

**Northwest/Idaho**

(509) 492-0846

[northwest@irricomp.com](mailto:northwest@irricomp.com)

**Midwest**

(308) 381-1509

[midwest@irricomp.com](mailto:midwest@irricomp.com)

**Great Lakes**

(308) 380-1378

[greatlakes@irricomp.com](mailto:greatlakes@irricomp.com)